



Place Dotted Fold Line on Low Edge of Door

Beveled Edge Door Only

Place Solid Fold Line on High Edge of Door

Use this end of Template for Beveled Edge Doors

Mark Center of Door thickness for 7/8" or 1" Dia. Hole Refer to Instruction Sheet

Fold on Edge of Door at proper Backset Line

2-3/8" (60)

BACKSET

5300LN ONLY

2-3/4" (70)

BACKSET

5300LN/5400LN/YMCL100

2-1/8" Dia. (54mm) Thru Door

5/16" Dia. (8mm) Thru Door 2 Holes

Vale Cylindrical Lever Lockset

5300 LN Series
5400 LN Series
YMCL100 Series

BACKSET

5300LN ONLY

2-3/8" (60)

BACKSET

5300LN/5400LN/YMCL100

2-3/4" (70)

5/32(4) x 1/8(3) Deep 2 places Both sides of Door

Fold on Edge of Door at proper Backset Line

Refer to Instruction Sheet for 7/8" or 1" Dia. Hole

Mark Center of Door thickness for

Square Edge Door Only

Use this end of Template for Square Edge Doors

Printed in U.S.A.

FOR REFERENCE ONLY
DO NOT USE AS A DIRECT CUTTING GUIDE
SCALE