

# Genuine Magalock® Selection Guide

## Out-Swing Door Magalock Selection Guide

Locks Mount on the Secure Side of the Door & Door Swings Away from Secure Side.  
Dual Doors Will Require Two Locks (X2), One for Each Leaf Except for DM62.

Preferred Application = **X** Also Acceptable for Application = **X**

DOOR TYPE	M32	M38	M62	DM62	M68	M82B	SAM	SAM2-24
<b>Glass Door</b> (w/ Aluminum Frame)	X	X	X*				X	X**
<b>Wooden Door</b> (Traffic Control)	X	X						X
<b>Wooden Door</b> (High Security)			X	X	X	X	X	
<b>Metal Door</b> (Traffic Control)	X	X						X**
<b>Metal Door</b> (High Security)			X	X	X	X	X	
<b>Herculite Door</b> (w/out Top or Bottom Rail)	X	X	X		X			
<b>Herculite Door</b> (w/Top or Bottom Rail)			X		X		X	X**

\* Requires an Offset Strike for proper installation.  
\*\*Not for use with Open Channel doors

## In-Swing Door Magalock Selection Guide

Locks Mounted on the Secure Side of the Door & Door Swings Toward Secure Side.  
Dual Doors Will Require Two Locks (X2), One for Each Leaf.

Preferred Application = **X** Also Acceptable for Application = **X**

DOOR TYPE	M32F	M38	M62F	M68	M82FB	SAM	SAM2-24
<b>Glass Door</b> (w/ Aluminum Frame)	X	X	X	X		X	X
<b>Wooden Door</b> (Traffic Control)	X	X					
<b>Wooden Door</b> (High Security)			X	X	X	X	
<b>Metal Door</b> (Traffic Control)	X	X					X
<b>Metal Door</b> (High Security)			X	X	X	X	

In-Swing Door Magalocks (except SAM & SAM2-24) will require a corresponding "Z" Bracket to mount the Strike Plate (Armature).  
M38 and M68 will require TJ-38 or TJ-68 Top Jamb Mounting Kit respectively.

## Sliding Door Magalock Selection Guide

Preferred Application = **X** Also Acceptable for Application = **X**

DOOR TYPE	M34R	SAM	SAM2-24
<b>All Sliding Door Types</b> (Dual)	X	X (X2)	X (X2)
<b>All Sliding Door Types</b> (Single)	X	X	X

**All Securitron Magalocks are Fail Safe Electric Locking Devices**