

BPS Linear Power Supply Selection Guide

	Plug-In	Hard Wired	Input Voltage	Output Voltage	Output Current	Battery Charger	UL Listed	# of Outputs	AC Loss and Low Battery Status	Manual Reset Option
BPS-12/24-1		X	120VAC	12/24VDC	1 AMP	X	X	1	AC LOSS ONLY	W/FAR
BPSH-12/24-1		X	220VAC	12/24VDC	1 AMP	X	X	1	AC LOSS ONLY	W/FAR
BPS-12-1		X	120VAC	12VDC	1 AMP	X	X	1		W/FAR-12
BPS-12-3		X	120VAC	12VDC	3 AMP	X	X	4	W/PSM-12	W/FAR-12
BPS-12-45		X	120VAC	12VDC	4.5 AMP	X	X	4	W/PSM-12	W/FAR-12
BPS-12-6		X	120VAC	12VDC	6 AMP	X	X	8	W/PSM-12	W/FAR-12
BPS-12-9		X	120VAC	12VDC	9 AMP	X	X	8	W/PSM-12	W/FAR-12
BPS-12-15		X	120VAC	12VDC	15 AMP	X	X	8	W/PSM-12	W/FAR-12
BPS-24-1		X	120VAC	24VDC	1 AMP	X	X	1		W/FAR-24
BPS-24-2		X	120VAC	24VDC	2 AMP	X	X	4	W/PSM-24	W/FAR-24
BPS-24-3		X	120VAC	24VDC	3 AMP	X	X	4	W/PSM-24	W/FAR-24
BPS-24-4		X	120VAC	24VDC	4 AMP	X	X	8	W/PSM-24	W/FAR-24
BPS-24-6		X	120VAC	24VDC	6 AMP	X	X	8	W/PSM-24	W/FAR-24
BPS-24-10		X	120VAC	24VDC	10 AMP	X	X	8	W/PSM-24	W/FAR-24
BPSM-12-6		X	120VAC	12VDC	6 AMP	X	X	8	X	W/FAR-12
BPSM-12-9		X	120VAC	12VDC	9 AMP	X	X	8	X	W/FAR-12
BPSM-12-15		X	120VAC	12VDC	15 AMP	X	X	8	X	W/FAR-12
BPSM-24-4		X	120VAC	24VDC	4 AMP	X	X	8	X	W/FAR-24
BPSM-24-6		X	120VAC	24VDC	6 AMP	X	X	8	X	W/FAR-24
BPSM-24-10		X	120VAC	24VDC	10 AMP	X	X	8	X	W/FAR-24
BACS-12-20		X	120VAC	12VAC	20 AMP		X	16		
BACS-24-10		X	120VAC	24VAC	10 AMP		X	8		

Plug In Power Supply Selection Guide

	Plug-In	Hard Wired	Input Voltage	Output Voltage	Output Current	Battery Charger	UL Listed	# of Outputs	AC Loss and Low Battery Status	Manual Reset Option
TP-12-3	X		120VAC	12VAC	3 AMP			1		
TP-24-2	X		120VAC	24VAC	1.5 AMP			1		
PSP-12	X		120VAC	12VDC	700mA			1		
PSP-12-3	X		120-220VAC	12VDC	3 AMP			1		
PSP-24	X		120VAC	24VDC	350mA			1		
PSP-24-15	X		120-220VAC	24VDC	1.5 AMP			1		