


FOR SHADED AREAS INDICATED:
WOOD: MUST BE ROUTED TO .075 [1,9] DEEP TO PROVIDE RECESSES IN DOOR FOR FLANGES OF SUPPORT COVER.
METAL: MATERIAL IN AREA MUST BE REMOVED AND (2) FLUSH TAB BRACKETS USED.

METAL OR WOOD:
OPTIONAL CUTOUT AREA REQUIREMENT
1/2" [12,7] RADIUS OR SQUARE CORNER ROUTE



DOOR AND FRAME PREPARATION INSTRUCTIONS:

DOOR:

1. POSITION THIS TEMPLATE ON THE CENTER OF THE HINGED EDGE OF THE DOOR AND PREPARE AS INSTRUCTED (SEE PRODUCT INSTALLATION MANUAL).
2. ONCE THE MOUNTING CENTERLINE AND HOLE LOCATIONS HAVE BEEN ESTABLISHED ON THE DOOR EDGE, LOCATE THE CORRESPONDING CENTERLINE ON THE DOOR FRAME.
NOTE: CENTERLINES ON DOOR AND FRAME MUST ALIGN WITH THE DOOR IN THE CLOSED POSITION.

FRAME:

1. USING THE CENTERLINE (DETERMINED IN STEP 2) AND THE 7.80" [198,1] EPT OR THE 16.30" [414,0] EPTL DIMENSION, MEASURE FROM THE CABLE HOLE IN THE DOOR AND MARK THE CENTER OF THE CABLE HOLE REQUIRED IN THE DOOR FRAME.

GENERAL NOTES:

1. DIMENSIONS WITHIN BRACKETS [XX,X] REPRESENT METRIC MEASUREMENT IN MILLIMETERS.
2. REFER TO THE PHYSICAL INSTALLATION SECTION OF THE EPT/EPTL INSTALLATION INSTRUCTIONS FOR DETAILED INFORMATION AND TROUBLESHOOTING.
3. THE RELATIONSHIP BETWEEN THE (2) FACE MOUNTING HOLES IS CRITICAL. DO NOT LET MARKINGS OR DRILLING WANDER.
4. DO NOT OVER TIGHTEN THE MOUNTING SCREWS.
5. DO NOT PHOTOCOPY THIS TEMPLATE !!! (SCALE MAY BE AFFECTED)

- (FLUSH TAB BRACKET MOUNTING)
1. DRILL 5/32" [3,9] DIA. THRU DOOR EDGE.
 2. 82-DEGREE COUNTERSINK THE HOLE TO APPROXIMATELY .28 [7,1] BODY DIAMETER FOR PROPER FLUSH SCREW MOUNTING. (2 PLACES/BOTH ENDS)